

IMPORTANT

Before installing, liberally coat all of the teeth on the gear with molybdenum disulfide (moly lube) to assure normal wear. Not doing so could cause premature wear of the distributor and cam gears.

FRM 33309