

MSD INSTALLATION INSTRUCTIONS

MSD Pro Mag Kill Switch PN 8111

Parts Included

- | | |
|------------------|----------------------------|
| 1 - Wire Harness | 2 - On/Off Position Labels |
| 1 - Switch Kit | 2 - Eye Crimp Connectors |

INSTALLATION

1. Mount the Switch in a position that is within easy reach of the driver.
2. Install the wiring harness to the Pro Mag Electronic Unit and route the harness to the Switch. Be sure the wires are routed away from sharp edges and engine heat sources. If it is necessary to cut the wires to length, shorten the outer sleeve of the harness two inches shorter than the wires.
3. Crimp the eye connectors to the stripped harness wires and connect them to the Switch using the supplied screws. It does not matter which terminal each wire is connected to. Make sure the connectors are fastened securely.
4. Depending on the position of the Switch, choose the correct On/Off label for your needs. The key notch on the Switch should match the notch on the label to read properly.




Figure 1 Wiring the Pro Mag Kill Switch.

Limited Warranty

MSD warrants this product to be free from defects in material and workmanship under its intended normal use*, when properly installed and purchased from an authorized MSD dealer, for a period of one year from the date of the original purchase. This warranty is void for any products purchased through auction websites. If found to be defective as mentioned above, it will be repaired or replaced at the option of MSD. Any item that is covered under this warranty will be returned free of charge using Ground shipping methods.

This shall constitute the sole remedy of the purchaser and the sole liability of MSD. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representation whether expressed or implied, including any implied warranty of merchantability or fitness. In no event shall MSD or its suppliers be liable for special or consequential damages.

*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD. Any modifications to this item or if it is used on an application other than what MSD markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD will accept no liability for custom applications.