

# MSD INSTALLATION INSTRUCTIONS

## RPM MODULE SELECTOR SWITCH

PN 8670	3,000 - 5,200 RPM
PN 8671	4,600 - 6,800 RPM
PN 8672	6,000 - 8,200 RPM
PN 8673	7,600 - 9,200 RPM
PN 8674	9,000 - 11,200 RPM

**ONLINE PRODUCT REGISTRATION:** Register your MSD product online. Registering your product will help if there is ever a warranty issue with your product and helps the MSD R&D team create new products that you ask for! Go to [www.msperformance.com/registration](http://www.msperformance.com/registration).

### Parts Included:

- 1 – RPM Module Selector Switch
- 4 – Mounting Screws

Mount the Switch close to the MSD Ignition in a position so it is accessible and easy to read. **The wires of the Switch cannot be lengthened.** Use the supplied mounting screws or the adhesive on the back panel of the unit to mount the Switch.

The 2-pin connector of the Switch plugs into the rpm module receptacle of the MSD component. There is no polarity so its position does not make a difference.




Figure 1 RPM Module Selector Installation.

